

**Date: January 2, 2015**

**To: Ferrule Fuse Block Customers**

**Subject: Conversion time frame for new ferrule fuse blocks up to 60A**

Eaton's Bussmann business has developed a new line of modular ferrule fuse blocks for Class CC, supplemental  $1\frac{3}{32}$ " x  $1\frac{1}{2}$ " (10 x 38mm) fuse, Class H(K), Class J, and Class R fuses. The new fuse blocks are fully modular with a snap-together design for tool-less assembly of multiple-pole blocks at point-of-use while reducing inventory and assembly time. Each block has provisions for DIN-Rail or panel mounting that permit the same block to be used for multiple applications. The new blocks also feature optional covers that enhance electrical safety with IP20 finger-safe ratings for the full wire size range of each block. Safety is further improved with an enhanced lockout/tagout feature, compatible with a broad array of lock designs. Covers are available with open circuit indication to speed troubleshooting and have provisions for an optional snap-in marker label for easy circuit identification.

As a result of launching these new fuse block products, we will be phasing out the legacy line of ferrule fuse blocks. The Class CC fuse block (BC603\_\_\_) and  $1\frac{3}{32}$ " x  $1\frac{1}{2}$ " (10 x 38mm) supplemental fuse block (BM603\_\_\_) products will continue to be available for purchase through June 30, 2015, or while inventory lasts. The 30A and 60A rated Class H(K), Class J, and Class R fuse block products will continue to be available for purchase through December 31, 2015, or while inventory lasts. Existing inventory is usable product and should not be returned. Below is a list of the current fuse block products that are being phased out along with the recommended new, replacement fuse block part numbers.

Description	Legacy Fuse Blocks		Replacement Fuse Blocks	
	Part #	UPC	New Part #	UPC
Class CC Fuse Block, 1 Pole	BC6031B	051712137430	BCM603-1C	051712486279
Class CC Fuse Block, 1 Pole	BC6031P	051712404549	BCM603-1P	051712486309
Class CC Fuse Block, 1 Pole	BC6031PQ	051712404693	BCM603-1PQ	051712486330
Class CC Fuse Block, 1 Pole	BC6031S	051712121873	BCM603-1S	051712486750
Class CC Fuse Block, 1 Pole	BC6031SQ	051712137393	BCM603-1SQ	051712486361
Class CC Fuse Block, 2 Pole	BC6032B	051712137423	BCM603-2C	051712486286
Class CC Fuse Block, 2 Pole	BC6032P	051712404556	BCM603-2P	051712486316
Class CC Fuse Block, 2 Pole	BC6032PQ	051712404709	BCM603-2PQ	051712486736
Class CC Fuse Block, 2 Pole	BC6032S	051712121880	BCM603-2S	051712486347
Class CC Fuse Block, 2 Pole	BC6032SQ	051712137409	BCM603-2SQ	051712486385
Class CC Fuse Block, 3 Pole	BC6033B	051712812894	BCM603-3C	051712486293
Class CC Fuse Block, 3 Pole	BC6033P	051712404563	BCM603-3P	051712486323
Class CC Fuse Block, 3 Pole	BC6033PQ	051712404716	BCM603-3PQ	051712486743
Class CC Fuse Block, 3 Pole	BC6033S	051712121897	BCM603-3S	051712486354
Class CC Fuse Block, 3 Pole	BC6033SQ	051712137416	BCM603-3SQ	051712486392
2 CC + Midget Fuse Block	BCCM6033PQ	051712814003	BCCMM603-3PQ	051712486521
2 CC + Midget Fuse Block	BCCM6033SQ	051712814010	BCCMM603-3SQ	051712486514
Midget Fuse Block, 1 Pole	BM6031B	051712736480	BMM603-1C	051712486484
Midget Fuse Block, 1 Pole	BM6031PQ	051712137317	BMM603-1PQ	051712486408
Midget Fuse Block, 1 Pole	BM6031SQ	051712736459	BMM603-1SQ	051712486446
Midget Fuse Block, 2 Pole	BM6032B	051712736497	BMM603-2C	051712486491
Midget Fuse Block, 2 Pole	BM6032PQ	051712137348	BMM603-2PQ	051712486422
Midget Fuse Block, 2 Pole	BM6032SQ	051712736466	BMM603-2SQ	051712486460
Midget Fuse Block, 3 Pole	BM6033B	051712736503	BMM603-3C	051712486507
Midget Fuse Block, 3 Pole	BM6033PQ	051712137379	BMM603-3PQ	051712486439
Midget Fuse Block, 3 Pole	BM6033SQ	051712736473	BMM603-3SQ	051712486477

Description	Legacy Fuse Blocks		Replacement Fuse Blocks	
	Part #	UPC	New Part #	UPC
Fuse Block, Class H, 250V 30A, 1 Pole	H25030-1C	051712146630	HM25030-1CR	051712512770
Fuse Block, Class H, 250V 30A, 1 Pole	H25030-1CR	051712146647	HM25030-1CR	051712512770
Fuse Block, Class H, 250V 30A, 1 Pole	H25030-1P	051712146654	HM25030-1PR	051712512749
Fuse Block, Class H, 250V 30A, 1 Pole	H25030-1PR	051712146661	HM25030-1PR	051712512749
Fuse Block, Class H, 250V 30A, 1 Pole	H25030-1Q	051712171960	HM25030-1QR	051712511186
Fuse Block, Class H, 250V 30A, 1 Pole	H25030-1S	051712146678	HM25030-1SR	051712512718
Fuse Block, Class H, 250V 30A, 1 Pole	H25030-1SR	051712146685	HM25030-1SR	051712512718
Fuse Block, Class H, 250V 30A, 2 Pole	H25030-2C	051712146692	HM25030-2CR	051712512787
Fuse Block, Class H, 250V 30A, 2 Pole	H25030-2CR	051712146708	HM25030-2CR	051712512787
Fuse Block, Class H, 250V 30A, 2 Pole	H25030-2P	051712146715	HM25030-2PR	051712512756
Fuse Block, Class H, 250V 30A, 2 Pole	H25030-2PR	051712146722	HM25030-2PR	051712512756
Fuse Block, Class H, 250V 30A, 2 Pole	H25030-2S	051712146739	HM25030-2SR	051712512725
Fuse Block, Class H, 250V 30A, 2 Pole	H25030-2SR	051712146746	HM25030-2SR	051712512725
Fuse Block, Class H, 250V 30A, 3 Pole	H25030-3C	051712146753	HM25030-3CR	051712511179
Fuse Block, Class H, 250V 30A, 3 Pole	H25030-3CR	051712146760	HM25030-3CR	051712511179
Fuse Block, Class H, 250V 30A, 3 Pole	H25030-3P	051712146777	HM25030-3PR	051712512763
Fuse Block, Class H, 250V 30A, 3 Pole	H25030-3PR	051712146784	HM25030-3PR	051712512763
Fuse Block, Class H, 250V 30A, 3 Pole	H25030-3S	051712146791	HM25030-3SR	051712512732
Fuse Block, Class H, 250V 30A, 3 Pole	H25030-3SR	051712146807	HM25030-3SR	051712512732
Fuse Block, Class R, 250V 30A, 1 Pole	R25030-1CR	051712147507	RM25030-1CR	051712511278
Fuse Block, Class R, 250V 30A, 1 Pole	R25030-1PR	051712147514	RM25030-1PR	051712511247
Fuse Block, Class R, 250V 30A, 1 Pole	R25030-1QR	051712151511	RM25030-1QR	051712511308
Fuse Block, Class R, 250V 30A, 1 Pole	R25030-1SR	051712147521	RM25030-1SR	051712511216
Fuse Block, Class R, 250V 30A, 2 Pole	R25030-2CR	051712147538	RM25030-2CR	051712511285
Fuse Block, Class R, 250V 30A, 2 Pole	R25030-2PR	051712147545	RM25030-2PR	051712511254
Fuse Block, Class R, 250V 30A, 2 Pole	R25030-2SR	051712147552	RM25030-2SR	051712511223
Fuse Block, Class R, 250V 30A, 3 Pole	R25030-3CR	051712147569	RM25030-3CR	051712511292
Fuse Block, Class R, 250V 30A, 3 Pole	R25030-3PR	051712147576	RM25030-3PR	051712511261
Fuse Block, Class R, 250V 30A, 3 Pole	R25030-3SR	051712147583	RM25030-3SR	051712511230
Fuse Block, Class H, 250V 60A, 1 Pole	H25060-1C	051712146814	HM25060-1CR	051712511339
Fuse Block, Class H, 250V 60A, 1 Pole	H25060-1CR	051712146821	HM25060-1CR	051712511339
Fuse Block, Class H, 250V 60A, 2 Pole	H25060-2C	051712146845	HM25060-2CR	051712511346
Fuse Block, Class H, 250V 60A, 2 Pole	H25060-2CR	051712146852	HM25060-2CR	051712511346
Fuse Block, Class H, 250V 60A, 3 Pole	H25060-3C	051712146876	HM25060-3CR	051712511353
Fuse Block, Class H, 250V 60A, 3 Pole	H25060-3CR	051712146883	HM25060-3CR	051712511353
Fuse Block, Class R, 250V 60A, 1 Pole	R25060-1CR	051712147590	RM25060-1CR	051712511360
Fuse Block, Class R, 250V 60A, 2 Pole	R25060-2CR	051712147606	RM25060-2CR	051712511377
Fuse Block, Class R, 250V 60A, 3 Pole	R25060-3CR	051712147613	RM25060-3CR	051712511384
Fuse Block, Class H, 600V 30A, 1 Pole	H60030-1C	051712146951	HM60030-1CR	051712511452
Fuse Block, Class H, 600V 30A, 1 Pole	H60030-1CR	051712146968	HM60030-1CR	051712511452
Fuse Block, Class H, 600V 30A, 1 Pole	H60030-1P	051712146975	HM60030-1PR	051712511421
Fuse Block, Class H, 600V 30A, 1 Pole	H60030-1PR	051712146982	HM60030-1PR	051712511421
Fuse Block, Class H, 600V 30A, 1 Pole	H60030-1S	051712147187	HM60030-1SR	051712511391
Fuse Block, Class H, 600V 30A, 1 Pole	H60030-1SR	051712147200	HM60030-1SR	051712511391
Fuse Block, Class H, 600V 30A, 2 Pole	H60030-2C	051712147217	HM60030-2CR	051712511469
Fuse Block, Class H, 600V 30A, 2 Pole	H60030-2CR	051712147224	HM60030-2CR	051712511469
Fuse Block, Class H, 600V 30A, 2 Pole	H60030-2P	051712147231	HM60030-2PR	051712511438
Fuse Block, Class H, 600V 30A, 2 Pole	H60030-2PR	051712147248	HM60030-2PR	051712511438
Fuse Block, Class H, 600V 30A, 2 Pole	H60030-2S	051712147255	HM60030-2SR	051712511407
Fuse Block, Class H, 600V 30A, 2 Pole	H60030-2SR	051712147262	HM60030-2SR	051712511407

Description	Legacy Fuse Blocks		Replacement Fuse Blocks	
	Part #	UPC	New Part #	UPC
Fuse Block, Class H, 600V 30A, 3 Pole	H60030-3C	051712147279	HM60030-3CR	051712511476
Fuse Block, Class H, 600V 30A, 3 Pole	H60030-3CR	051712147286	HM60030-3CR	051712511476
Fuse Block, Class H, 600V 30A, 3 Pole	H60030-3P	051712147293	HM60030-3PR	051712511445
Fuse Block, Class H, 600V 30A, 3 Pole	H60030-3PR	051712147309	HM60030-3PR	051712511445
Fuse Block, Class H, 600V 30A, 3 Pole	H60030-3S	051712147316	HM60030-3SR	051712511414
Fuse Block, Class H, 600V 30A, 3 Pole	H60030-3SR	051712147323	HM60030-3SR	051712511414
Fuse Block, Class R, 600V 30A, 1 Pole	R60030-1CR	051712147682	RM60030-1CR	051712511544
Fuse Block, Class R, 600V 30A, 1 Pole	R60030-1PR	051712147699	RM60030-1PR	051712511513
Fuse Block, Class R, 600V 30A, 1 Pole	R60030-1SR	051712147705	RM60030-1SR	051712511483
Fuse Block, Class R, 600V 30A, 2 Pole	R60030-2CR	051712147712	RM60030-2CR	051712511551
Fuse Block, Class R, 600V 30A, 2 Pole	R60030-2PR	051712147729	RM60030-2PR	051712511520
Fuse Block, Class R, 600V 30A, 2 Pole	R60030-2SR	051712147736	RM60030-2SR	051712511490
Fuse Block, Class R, 600V 30A, 3 Pole	R60030-3CR	051712147743	RM60030-3CR	051712511568
Fuse Block, Class R, 600V 30A, 3 Pole	R60030-3PR	051712147750	RM60030-3PR	051712511537
Fuse Block, Class R, 600V 30A, 3 Pole	R60030-3SR	051712147767	RM60030-3SR	051712511506
Fuse Block, Class H, 600V 60A, 1 Pole	H60060-1C	051712147330	HM60060-1CR	051712511575
Fuse Block, Class H, 600V 60A, 1 Pole	H60060-1CR	051712147347	HM60060-1CR	051712511575
Fuse Block, Class H, 600V 60A, 2 Pole	H60060-2C	051712147361	HM60060-2CR	051712511582
Fuse Block, Class H, 600V 60A, 2 Pole	H60060-2CR	051712147378	HM60060-2CR	051712511582
Fuse Block, Class H, 600V 60A, 3 Pole	H60060-3C	051712147392	HM60060-3CR	051712511599
Fuse Block, Class H, 600V 60A, 3 Pole	H60060-3CR	051712147408	HM60060-3CR	051712511599
Fuse Block, Class R, 600V 60A, 1 Pole	R60060-1CR	051712147774	RM60060-1CR	051712511605
Fuse Block, Class R, 600V 60A, 2 Pole	R60060-2CR	051712147781	RM60060-2CR	051712511612
Fuse Block, Class R, 600V 60A, 3 Pole	R60060-3CR	051712147798	RM60060-3CR	051712511629
Class J fuse block 600V30A-Lug-1 pole	J60030-1C	051712404570	JM60030-1CR	051712514637
Class J fuse block 600V30A-Lug-1 pole	J60030-1CR	051712148412	JM60030-1CR	051712514637
Class J fuse block 600V30A-PP-1 pole	J60030-1P	051712404587	JM60030-1PR	051712514606
Class J fuse block 600V30A-PP-1 pole	J60030-1PR	051712175357	JM60030-1PR	051712514606
Class J fuse block 600V30A-screw-1 pole	J60030-1S	051712404594	JM60030-1SR	051712514576
Class J fuse block 600V30A-Lug-2 pole	J60030-2C	051712404600	JM60030-2CR	051712514644
Class J fuse block 600V30A-Lug-2 pole	J60030-2CR	051712148207	JM60030-2CR	051712514644
Class J fuse block 600V30A-PP-2 pole	J60030-2P	051712404617	JM60030-2PR	051712514613
Class J fuse block 600V30A-PP-2 pole	J60030-2PR	051712175371	JM60030-2PR	051712514613
Class J fuse block 600V30A-screw-2 pole	J60030-2S	051712404624	JM60030-2SR	051712514583
Class J fuse block 600V30A-Lug-3 pole	J60030-3C	051712404631	JM60030-3CR	051712514651
Class J fuse block 600V30A-Lug-3 pole	J60030-3CR	051712148405	JM60030-3CR	051712514651
Class J fuse block 600V30A-PP-3 pole	J60030-3P	051712404648	JM60030-3PR	051712514620
Class J fuse block 600V30A-PP-3 pole	J60030-3PR	051712175395	JM60030-3PR	051712514620
Class J fuse block 600V30A-screw-3 pole	J60030-3S	051712404655	JM60030-3SR	051712514590
Class J fuse block 600V30A-screw-3 pole	J60030-3SR	051712175401	JM60030-3SR	051712514590
Class J fuse block 600V 60A - 1 pole	J60060-1C	051712404662	JM60060-1CR	051712514668
Class J fuse block 600V 60A - 1 pole	J60060-1CR	051712148214	JM60060-1CR	051712514668
Class J fuse block 600V 60A - 2 pole	J60060-2C	051712404679	JM60060-2CR	051712514675
Class J fuse block 600V 60A - 2 pole	J60060-2CR	051712148221	JM60060-2CR	051712514675
Class J fuse block 600V 60A - 3 pole	J60060-3C	051712404686	JM60060-3CR	051712514682
Class J fuse block 600V 60A - 3 pole	J60060-3CR	051712148238	JM60060-3CR	051712514682
IEC Fuse block 700V 100A - 1 pole	J70100-1CR	051712556774	JM70100-1CR	051712514729
IEC Fuse block 700V 100A - 2 pole	J70100-2CR	051712566698	JM70100-2CR	051712514736
IEC Fuse block 700V 100A - 3 pole	J70100-3CR	051712566704	JM70100-3CR	051712514743

Many of the new fuse blocks have a different mounting hole layout and a reduced footprint compared to the legacy blocks and may not be a direct drop-in replacement. You are encouraged to review the product data sheet or samples to make sure the new fuse blocks will fit into your existing panel design without any modifications to the panel.

If you have any questions regarding this product change notice or would like to secure a sample, please contact your local Bussmann representative.

Kind Regards,

Darren McDowell  
Product Manager

[DarrenL.McDowell@Eaton.com](mailto:DarrenL.McDowell@Eaton.com)